


1 Comp. Loc. Airbag

- ◆ ⇒ "1.1 Airbag Overview", page 1
- ◆ ⇒ "1.2 Crash Sensor", page 2
- ◆ ⇒ "1.3 Seat Belt Overview", page 3

1.1 Airbag Overview


- 1 - Front passenger knee airbag igniter -N296-
- 2 - Front passenger airbag deactivation key switch -E224-
- 3 - Front passenger airbag igniter 1 -N131-
- 3 - Front passenger airbag igniter 2 -N132-
- 3 - Front passenger airbag release valve igniter -N491-
- 4 - Front passenger thorax airbag igniter -N200-
- 5 - Front passenger head curtain airbag igniter -N252-
- 6 - Airbag control module - J234
- 7 - Front passenger rear thorax airbag igniter -N202-
- 8 - Driver head curtain airbag igniter -N251-
- 9 - Battery interrupt igniter -N253-
- 10 - Driver side rear thorax airbag igniter -N201-
- 11 - Driver thorax airbag igniter -N199-
- 12 - Driver airbag igniter -N95-
- 12 - Driver airbag release valve igniter -N490-
- 13 - Steering column electronics control module -J527
 - ❑ Airbag spiral spring/return spring with slip ring - F138
 - ❑ Steering angle sensor - G85
- 14 - Airbag indicator lamp -K75
- 15 - Driver knee airbag igniter -N295-
- 16 - Front passenger airbag -disabled- indicator lamp -K145-



1.2 Crash Sensor

- 1 - Driver front airbag crash sensor -G283-
☐ On retainer for headlight housing
- 3 - Front passenger front airbag crash sensor -G284-
☐ On retainer for headlight housing
- 5 - Front passenger side airbag crash sensor -G180-
☐ In door
- 7 - Front passenger side rear side airbag crash sensor -G257-
☐ On inside of wheel housing behind sill panel trim
- 10 - Driver side rear side airbag crash sensor -G256-
☐ On inside of wheel housing behind sill panel trim
- 11 - Driver side airbag crash sensor -G179-
☐ In door

Copyright © 2015 Audi AG. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



A69-10781

1.3 Seat Belt Overview



Illustration shows seat belts in sedan with fixed rear seat backrest.

- 1 - Front passenger seat belt tensioner igniter 1 -N154-
- 1 - Right front seat belt tensioner control module J855
- 1 - Front passenger belt force limiter -G552-
- 4 - Front passenger side rear seat belt tensioner igniter -N197-
- 5 - Center rear seat belt tensioner igniter -N198-
- 8 - Driver side rear seat belt tensioner igniter -N196-
- 10 - Driver seat belt tensioner igniter 1 -N153-
- 10 - Left front seat belt tensioner control module J854
- 10 - Driver belt force limiter -G551-

